

D-Motor International bvba Houtekiestraat 11 B-8540 Deerlijk, Belgium

Tel. +32 56 49 81 49 Info@d-motor.eu **SERVICE BULLETIN D-MOTOR**

Service Bulletin NO. 2019-016

<u>SUBJECT :</u> Mounting place of the Engine Controller Unit (ECU) <u>MODELS AFFECTED :</u> All models

TIME OF COMPLIANCE : new mounting

AFFECTED SERIAL NUMBER(S) : All engines

The ECU or Engine Control Unit is built with three independend computer systems. The computer systems are operated by a internal clock (Oscillator).

The clock of the computer systems can be heavily disturbed by electromagnetic fields.



It is important that the distance between the ignition coil set (both LF26 and LF39) is kept as big as possible.

A aluminium or metal plate does not shield the ECU unit form those electromagnetic fields enough.

The operating coils could disturb the ECU and eventually damage the unit severely !

Please take notice that all components should be grounded (connected tot he frame) to avoid the 'antenna effect' as much as possible.

Service Bulletin 2019 - 016										
ISSUED			REVISED			Pages	Rev.			
Day	Month	Year	Day	Month	Year	2	1			
08	07	2019	12	07	2019					







D-MOTOR

Do not mount the ECU directly above or below the Ignition Coil set !

Example of how NOT to install the ECU :



Service Bulletin 2019 - 016										
ISSUED			REVISED			Pages	Rev.			
Day	Month	Year	Day	Month	Year	2	1			
08	07	2019	12	07	2019					

http://www.d-motor.eu

info@d-motor.eu